burkert ELUID CONTROL SYSTEMS



Electrical position feedback for pneumatically operated process valves

- · Fast and easy installation
- · Compact design







Product variants described in the data sheet may differ from the product presentation and description.

Can be combined with



Type 0330/0331

Direct-acting 2/2 or 3/2 way pivoted armature valve



Type 2XXX

Accessories for pneumatic stroke and rotary actuators

Type description

The electrical position feedback Type 1060 is designed for integrated mounting on CLASSIC Series process valves . Due to its simple and a very compact design, the feedback can easily be mounted on a valve. Valve positions are remotely reported electrically according to switch type: open, closed.



Table of contents

| 1. | Ger | neral technical data | 3 |
|----|--------------|--|---|
| 2. | Din | nensions | 4 |
| 3. | Dev | vice/Process connections | 5 |
| | 3.1. | Electrical connection | 5 |
| 4. | Pro | oduct installation | 6 |
| | 4.1. | Electrical connection instruction | 6 |
| 5. | Ord | dering information | 7 |
| | 5.1. 5.2. | Bürkert eShop – Easy ordering and quick delivery | |



1. General technical data


| Detailed information can be found in chapter "2. Dimensions" on page 4. |
|---|
| |
| Plastic |
| Plastic |
| |
| 1 switch over contact |
| Electrical feedback (alarm-, emergency-, off-, follow-circuits, etc.) for solenoid valves, diaphragm valves, piston valves, gate valves |
| |
| |
| Maximum 5 A ohmic and inductive contact load Filament load max. 0.5 A |
| Maximum 0.25 A ohmic contact load Maximum 0.02 A inductive load Maximum 0.02 A filament load |
| |
| |
| Can be rotated through 4 x 90° |
| Solder terminals |
| With cylindrical screw M3 x 28 resp. M3 x 30 |
| 59 mm |
| |
| 125 °C |
| IP65 DIN 40050 |
| |

<u>burkert</u>

2. Dimensions

Note:

Dimensions in mm






3. Device/Process connections

3.1. Electrical connection

| Connection | Pin | Pin Assignment |
|------------|-----|----------------|
| 2 3 1 | 1 | Input |
| | 2 | Break contact |
| | 3 | Make contact |






4. Product installation

4.1. Electrical connection instructions

- · Loosen screw in cap (2) take out contact insert.
- · Feed cable through union nut (6).
- Connect according to the circuit (see electrical connection scheme).
- Insert contact insert (3) into cap (5) and clip in.
- · Screw on cap (2) upon the socket with cap screw (4) ensuring that the flat seal (1) is securely positioned.
- Check the valve for function.



| No. | Description |
|-----|----------------|
| 1 | Flat seal |
| 2 | Screw |
| 3 | Contact insert |
| 4 | Cylinder screw |
| 5 | Cap |
| 6 | Union nut |

5. Ordering information

5.1. Bürkert eShop - Easy ordering and quick delivery



Bürkert eShop - Easy ordering and fast delivery

You want to find your desired Bürkert product or spare part quickly and order directly? Our online shop is available for you 24/7. Sign up and enjoy all the benefits.

Order online now

5.2. Bürkert product filter



Bürkert product filter - Get quickly to the right product

You want to select products comfortably based on your technical requirements? Use the Bürkert product filter and find suitable articles for your application quickly and easily.

Try out our product filter

Bürkert - Close to You

